



INSTALLATION INSTRUCTIONS

[CARBAHN.COM/INSTRUCTIONS](https://carbahn.com/instructions)

X5, X6, X7 Strut Brace Set

CARBAHN PART #:

CBB12-00-5660 & CBB12-00-5662



US Based Support

866-558-4314

Sales@CarBahn.com

CarBahn.com

Follow Us: [@CarBahnOfficial](https://twitter.com/CarBahnOfficial)

These instructions assume that the person installing these parts is a *BMW* and are *NOT* step by step instructions on how to disassemble and reassemble the car.

1. Remove the driver side front strut brace.
2. Install the CarBahn driver side strut brace. There is a DS etched on the bottom of the driver side strut brace. Torque the bolts as indicated in Table 1.
3. Remove the passenger side front strut brace.
4. Install the CarBahn passenger side strut brace. There is a PS etched on the bottom of the passenger side strut brace. Torque the bolts as indicated in Table 1.

Table 1

Bolt	Tightening Torque
M10 E-Torx	56Nm + 90°
M8 Hex	28Nm