



INSTALLATION INSTRUCTIONS

[CARBAHN.COM/INSTRUCTIONS](https://carbahn.com/instructions)

CARBAHN G8X M2 M3 M4 FIRST EDITION MONOBALL KIT

**CARBAHN PART #:
CBG8X-3101**



US Based Support
866-558-4314
Sales@CarBahn.com
CarBahn.com

CBG8X-3107/CBG8X-3101 Mono-Ball Kit G8X M3/M4

These instructions assume that the person installing these parts is a BMW CERTIFIED MECHANIC and are NOT step by step instructions on how to disassemble and reassemble the car!

1. Step one of installing this kit will require you to follow factory BMW procedures for removing both the driver and passenger side front caster arms.
2. With driver and passenger side caster arms out of the car you will now need to press out the factory rubber bushings from both arms with the appropriate adapters and press.



3. Once the factory bushings have been pressed out of the arms, start the assembly process by applying bearing grease to completely cover the inner face of both arms. Then press the new mono ball housings into the caster arms **from the chamfered side of the arm. (Note: Never Press on mono ball directly, you must use a press tool that only presses on the housing. Pressing on the mono ball will damage it and void the warranty.** Make sure that the housing is pressing into the arm square and not cocked to one side or the other. If excessive pressure is required to press housings into the arms **STOP** immediately and double check it is square in the boar of the arm before proceeding.)

CBG8X-3107/CBG8X-3101 Mono-Ball Kit G8X M3/M4



4. After pressing the mono ball housings into both arms, you can now locate the threaded hat and M5 hardware provided. Insert the hardware through the mono ball housing and thread into hat locking the the housing into the arm. Torque all 8 M5 hardware on both arms to 95-inch pounds in a crisscross pattern. (Note: when torquing hardware in crisscross pattern make sure you go through the sequence at least two times per arm to make sure that the housing and threaded hat have fully seated.)



CBG8X-3107/CBG8X-3101 Mono-Ball Kit G8X M3/M4

5. With the mono ball housings fully installed into the arms and you are confident that all the hardware has been torqued to the proper specifications as well as the housings being fully seated you can now refer back to the factory BMW procedures to reinstall the driver and passenger caster arms using the supplied spacers.



6. Finally, after installation is complete an alignment must be performed.