



INSTALLATION INSTRUCTIONS

CARBAHN.COM/INSTRUCTIONS

**BMW 2/3/4 Series (Non M) & Z4 Suspension
Links**

CARBAHN PART #:

CBB12-20-7080



US Based Support

866-558-4314

Sales@CarBahn.com

CarBahn.com

Follow Us: @CarBahnOfficial

These instructions assume that the person installing these parts is a *BRAND CERTIFIED MECHANIC* and are *NOT step by step instructions on how to disassemble and reassemble the car.*

4. With OEM Links removed, you can proceed to install the CarBahn links. Use the stock bolts, washers and nuts to secure the links to the chassis.

Note: If you are unsure if the correct arms were removed, you can use the provided CarBahn links and make sure the center-to-center distance of the holes are the same as the OEM ones you removed. If they are not the same or close to the same, the wrong oem parts were removed.

5. After the installation is complete, an alignment must be performed.